

User Manual for the Honeywell 1400G



This manual will cover the necessary barcodes for programming the Honeywell 1400G scanner.

Carriage Return

Sometimes, your barcode may not be configured to press the **[ENTER]** key after scanning. If you scan your item and it doesn't automatically ring anything up OR if you scan it into notepad and you see the cursor blinking on the same line, you must scan the barcode below to program the scanner to do so.



VSUFCR.

**Add CR Suffix
All Symbologies**

UPC-A and UPC-E Codes

Most grocery, liquor, or tobacco items contain either a UPC-A or a UPC-E code.

UPC-A sample showing the number system and check digit:



UPC-E0 sample showing the number system and check digit:



UPC-A

CODES FOR UPC-A NUMBER SYSTEM



UPANSX1.
*** On**



UPANSX0.
Off

CODES FOR UPC-A CHECK DIGIT



UPACKX1.
*** On**



UPACKX0.
Off

UPC-E

CODES FOR UPC-E LEADING ZERO



UPENSX1.
On



UPENSX0.
*** Off**

CODES FOR UPC-E CHECK DIGIT



UPECKX1.
On



UPECKX0.
*** Off**